

WELCOME

TO YOUR EPRO SELECT CORDLESS VACUUM SOLUTION



At ePro Select, everyday products are extraordinary products.

The Cordless Vacuum with 6 Bonus Accessory Tools is no exception.

The Highly Efficient High-Speed Digital Motor is comparable to the most powerful cordless vacuums in the market at a far greater value, exclusive to our members.

The digital brushless motor is the key to its heavy-duty performance in a lightweight, versatile configuration, with cordless convenience, ergonomic efficiency, and interchangeable accessory tools, and a wall mount all included!

Extra Special Value, The Right Fit for the Job

Expect more with 6 Bonus accessory tools included with purchase. See Quick Start Guide on reverse side to visualize all the different ways you can use your ePro Select Cordless Vacuum system from floor to ceiling, and small surfaces and spaces in between.

**PLEASE SCAN
QR code**
with camera app
to view website



Visit our **Support** page to
download User Guide and
other helpful materials

eProSelect.com

The Right Fit for the Job

Select from 6 Bonus Accessory Tools

Floor to Ceiling


Use Extension Rod

Connect to **Motorized Brush Roller** for all floor surfaces and **Flexible Bending Adaptor** for under furniture

- Connect **Long Crevice Tool** for baseboards, trim, high and low corners.
- Connect the **Brush attachments** for curtains and drapes.
- Attach the **Wide Nozzle Brush** for gentle cleaning of curtains, draperies, and blinds.

ACCESSORY TOOL SET

- ① Mini Motorized Brush Roller
- ② Metal Extension Rod
- ③ Extended Crevice Tool
- ④ Wide Nozzle Brush Tool
- ⑤ 2-in-1 Brush/Crevice Tool
- ⑥ Extension Hose
- ⑦ Flexible Bending Adapter
- ⑧ Motorized Floor Brush Roller with LED lights



Smaller Spaces

Use as Hand Vacuum

Without the Extension Rod, connect to **Mini Motorized Brush Roller** for stairs and small space surfaces.

- Combine the **Extension Hose** with **Long Crevice Tool** or **Brush attachments** for cleaning the interior of a car, truck or RV.
- Use **Crevice** and **Brush Tools** without Extension Hose for more delicate fabric surfaces or hard to reach spots.
- Attach the **Wide Nozzle Brush** for bedding, fabrics, and window sills.
- Attach the **Extension Hose** plus the **Crevice** or **Brush Tools** for deep-cleaning car interiors, under seats, and in between.

 ALLOW BATTERY PACK UP TO 3.5 HOURS TO FULLY RECHARGE

BATTERY CHARGING

Before first use the detachable lithium-ion battery must be fully charged. It can be charged either installed or uninstalled by connecting the power cord to the recharging port and a standard electrical outlet.

ePro Select

For assistance with your product, please email service@eproselect.com or visit our website eProSelect.com

©2023 Distributed by ePro USA LLC. Austin, TX. ©2023 ePro USA LLC. All rights reserved.