

ePro Select

WELCOME

Exclusively at
sam's club 

TO YOUR 5-IN-1 ULTIMATE VACUUM




**At ePro Select,
everyday products are
extraordinary products.**

The 5-in-1 Ultimate Cordless Vacuum System is no exception. Welcome to your ultimate cleaning companion designed for versatility and efficiency. This cutting-edge vacuum seamlessly transitions from a robust wet and dry vacuum and floor washer to a convertible stick and handheld device, ensuring you can tackle any cleaning task with ease.

Equipped with a suite of interchangeable tools, it effortlessly adapts to various surfaces and messes, whether it's dry debris, liquid spills, or hard-to-reach corners. Experience unparalleled cleaning power and flexibility, all in one sleek, user-friendly system.

Extra Special Value, The Right Fit for the Job

Expect more with this whole-home cleaning system that assembles into 5 unique configurations and includes 17-pieces, including a variety of interchangeable cleaning tools, an extra battery pack, a spare wet/dry roller brush, and extra HEPA and sponge filters. See our Quick Reference Guide on reverse side to get started.



WE WANT TO HEAR FROM YOU!



Review Your ePro Select Vacuum Cleaner

Hope you're enjoying your new ePro Select vacuum cleaner! We'd love to hear about your experience. Your review helps others make informed decisions and improve our products.

Thanks for your support! — ePro USA LLC

**SCAN TO
VISIT
SUPPORT
PAGE**



Visit our **Support** page to download User Guide and other helpful materials
eproselect.com/eproselect-support
eProSelect.com




ALLOW BATTERY
PACK UP TO
2.5 HOURS TO
FULLY RECHARGE

BATTERY CHARGING

Before first use the removable lithium-ion battery must be fully charged. Batteries can be charged two ways:

- 1 **MOTOR HOUSING** inserted into the **WET/DRY tank** while docking into the **Storage/Charging Base**.
- 2 Individual battery inserted into the **SPARE BATTERY COMPARTMENT** located on the rear of the **Storage/Charging Base**.



MOTORIZED WET/DRY ROLLER BRUSH

Attach the **Interchangeable Motor Housing** (A) to the **Motorized Wet/Dry Roller Brush with Water Tanks** (B) for hard, sealed floor surfaces.

B



A
**INTERCHANGEABLE
MOTOR HOUSING**
is used to power both
the wet/dry vacuum
and the convertible
stick to hand vacuum.




Extension
Rod F

Stick Vacuum
Floor Head G

F

G



Floor to Ceiling

Use Extension Rod

- Connect the **Brush attachment** (C) to the **Extension Rod** (F) for drapes and blinds.
- Connect the **Long Crevice Tool** (D) to the **Extension Rod** (F) for baseboards and trim, high and low corners.

Smaller Spaces

Use as Hand Vacuum

- Connect the **Motor Housing** (A) to the **Mini Motorized Brush Roller** (E) for stairs and small space surfaces.
- Attach the **2-in-1 Brush/Crevice Tool** (C) for dressers, shelves, and keyboards.
- Use the **Long Crevice Tool** (D) or **2-in-1 Brush/Crevice** (C) attachments for deep-cleaning the car, truck or RV interiors, under seats, or hard to reach spots.

CONVERTIBLE STICK & HAND VACUUM

Connect the **Interchangeable Motor Housing** (A) to the **Extension Rod** (F) and the **Stick Vacuum Floor Head** (G) for hard floors and low-pile carpets.

SCAN TO VISIT
SUPPORT PAGE



For assistance with your product, please email service@eproselect.com or visit Support page at <https://www.euproselect.com/euproselect-support>



GIVE US A CALL!
1-877-858-EPRO (3776)